

EX. NO.: 5 Customized ping command to test the server connectivity without using socket.
DATE: 18.08.2025

AIM:

To study packet sniffing concept and implement it without using raw sockets.

Algorithm:

1 . Define a Packet Callback Function:

- Define a function `packet_callback(packet)` that processes each captured packet.
- Check if the packet contains an IP layer (IP in packet).

2 . Extract Packet Details:

- If the packet contains the IP layer, retrieve the protocol number, source IP, and destination IP from the IP layer (`packet[IP]`).
- Initialize `protocol_name` as an empty string.

3 . Determine Protocol Type:

- Use conditional statements to map protocol numbers to protocol names:
 - 1 for ICMP
 - 6 for TCP
 - 17 for UDP
 - Any other protocol number as "Unknown Protocol".

4 . Display Packet Details:

- Print the protocol name, source IP, and destination IP for each captured packet.
- Print a separator line to distinguish between different packets.

5 . Main Function:

- Use a try block to handle exceptions.
- Set the interface name (e.g., "Ethernet" or "Wi-Fi") based on the system's network configuration.
- Call the sniff function to capture packets on the specified network interface with:
 - `iface=interface_name` for the interface name.
 - `prn=packet_callback` to call the callback function for each packet.
 - `filter="ip"` to capture only IP packets.
 - `store=0` to avoid storing packets in memory.

6 . Error Handling:

- In the except block, print an error message if an exception occurs, and advise running with elevated privileges or checking the interface name.

7 . Execute the Program:

- In the main function, call `main()` to start the packet-sniffing process.

CODE:

```
from scapy.all import sniff
from scapy.layers.inet import IP, TCP, UDP, ICMP

def packet_callback(packet):
    if IP in packet:
        ip_layer = packet[IP]
        protocol = ip_layer.proto
        src_ip = ip_layer.src
        dst_ip = ip_layer.dst

        # Determine the protocol
        protocol_name = ""
        if protocol == 1:
            protocol_name = "ICMP"
        elif protocol == 6:
            protocol_name = "TCP"
        elif protocol == 17:
            protocol_name = "UDP"
        else:
            protocol_name = "Unknown Protocol"

        # Print packet details
        print(f"Protocol: {protocol_name}")
        print(f"Source IP: {src_ip}")
        print(f"Destination IP: {dst_ip}")
        print("-" * 50)

def main():
    try:
        # Replace 'Ethernet' with your actual network interface name from ipconfig output
        interface_name = "Ethernet" # or "Wi-Fi" if using wireless

        # Capture packets on the specified network interface
        sniff(iface=interface_name, prn=packet_callback, filter="ip", store=0)
    except Exception as e:
```

```
print(f"Error: {e}")  
    print("Make sure you are running the script with elevated privileges (e.g., sudo) and check  
the interface name.")  
  
if __name__ == "__main__":  
    main()
```

RESULT :

packet sniffing concept and implement it without using raw sockets is studied.

